



# HOSHIZAKI AMERICA, INC.

## SERVICE BULLETIN

**SB04-0001**

March 1, 2003

Page 1 of 1

### **Subject: -AAC REACH IN DEFROST BY-PASS INSTRUCTIONS**

The -AAC SafeTemp® reach-in freezers go through a defrost cycle any time they are started, after power has been interrupted. This is a normal part of the sequence and is built into the control module. During troubleshooting it is possible to by-pass this initial defrost so that the technician does not have to wait through a defrost each time the unit is re-started.

To by-pass the initial defrost follow these instructions:

1. Press the “UP” arrow and the “F” Button at the same time that the power switch (toggle) is turned on.
2. The initial defrost will be by-passed and after a 5 minute delay the unit will start in refrigeration.

Press at the same time the  
power switch is moved to  
“ON”

