



HOSHIZAKI AMERICA, INC.

SERVICE BULLETIN

SB04-0010

July 20, 2004

Page 1 of 2

Subject: FREEZER OVERFLOW PAN ELIMINATION

Beginning in February of 2004 the external condensate overflow pan will no longer be supplied with any reach-in freezers. This pan was only necessary in rare circumstances and in many cases was never installed.

The freezers will continue to have mounting holes for the overflow pan in the event it is needed. Simply order the parts below from your local distributor and follow the attached instructions.

Bracket	4A0878-01
Bracket	4A0879-01
Overflow Pan	4A2081-01
T2 Screw (4)	7P32-0408


For questions regarding this issue please contact the Technical Support department by e-mail at techsupport@hoshizaki.com or phone at 1-800-233-1940.

FREEZER OVERFLOW PAN INSTALLATION INSTRUCTIONS

6. OVERFLOW PAN (if applicable)

Note: For units with an electrically heated condensate pan, see section "8.")

- 1) Assemble the overflow pan's brackets by engaging the tab on the bracket through the hole in the unit bottom and securing with the four mounting screws provided.
- 2) Slide the plastic pan into place under the vinyl hose on the back of cabinet.



7. DRAIN CONNECTION (if applicable)

- 1) This unit is provided with an energy efficient automatic condensate water disposal system and normally requires no drain connection.
- 2) High relative humidity and frequent door openings for long periods of time could cause excessive condensate water to form.
- 3) If this occurs, condensate water will drain out through the overflow drain tube located inside the back wall of the cabinet and into the Overflow Pan.
- 4) In the unlikely event that water is found in the Overflow Pan, **call your HOSHIZAKI Service Representative for assistance.**