



HOSHIZAKI AMERICA, INC.

SERVICE BULLETIN

SB21-0008

December 1, 2021

Page 1 of 1

Subject: Flaker/DCM replacement bearing sleeve (NLA)

We have been informed that our vendor will no longer be able to supply the Flaker/DCM bearing sleeve. Due to the availability of replacement parts this will also eliminate the bearing re-press program. See the list below for part numbers that will no longer be available.

In the event bearings need to be replaced in a Flaker or DCM product, please order the appropriate extruding head and lower housing based on the model specific parts manual. It is recommended that the extruding head and lower housing be replaced as a set. It is also important to replace the seal bolts when replacing the extruding head.

Bearing wear should be checked at least once per year. Please refer to individual model's instruction manual for details on the bearing inspection process.

Bearing part numbers that are NLA
SP88-7311
SP88-7312
SP88-7313
SP88-7314
SP88-7316
SP88-7317

If you have question concerning this Service Bulletin, please contact the Technical Support department techsupport@hoshizaki.com or 1-800-233-1940.